



**emendee**  
cleaninginstructions

## primary filter

This filter should be changed after each client. This helps stop the bacterial transfer that can happen between clients. It is also a requirement of Workplace Health & Safety (WH & S). The cleaner you keep this filter, the cleaner the whole unit will stay. \* So make sure you don't forget! \*

1. Turn off the machine
2. Lift straight up out of table
3. Carry the filter face up over to washbasin
4. Turn filter over
5. Run water on medium to hard pressure through filter to dispose of the dust the way it was trapped.
6. Wring filter out thoroughly and then allow to dry flat
7. If you are using the filter immediately – lay in a towel and twist tightly so that the filter is almost dry and then replace in table - if not, place flat to dry. (A plate drainer or file holder works well for multiple filters.
8. If you have spilled acrylic or nail polish onto the filter – wipe off immediately with acetone. If you leave it to dry you can damage the filter when trying to pick it off
9. Each month, after rinsing the filters, you can place the filter in the washing machine on low water, no detergent & run a normal cycle to refresh the filters.
10. Take out of the machine straight after spin cycle and lay flat to dry. The filters dry in whatever shape they are in.
11. At **NO** time should you soak the filters in water as although they are a high-tech foam, they are still a foam and as such they will break down.

## secondary filters

This filter is to trap any excess dust that may penetrate the primary filter and is the final filter for the air that you are breathing.

1. With the machine **on**, but **without** the primary filter in position, blow a hairdryer down inside the unit from the top to dislodge any stray dust and force it into the secondary filters.
2. Turn off the emendee nail unit
3. On the client side of the workstation you will find a T clip on the filter guards. Undo this clip and release the guard.
4. Remove the Velcro strap from around the neck of the filters.
5. Release Velcro anchor dot from end of bag.
6. Slide filters off the neck of the unit
7. Carefully – making sure to avoid any inhalation of dust from movement - Vacuum the dust from the bags. You will see the filter fabric turn dark as the dust is drawn out of the filter fabric
8. Replace filters on the **emendee** workstation
9. Replace the Velcro straps tightly
10. Every 3 months after vacuuming, you can place the filter in the washing machine on low water. Allow to wash a full cycle.
11. Take out of the machine straight after spin cycle and stand on end to dry. The filters dry in whatever shape they are in.
12. At **NO** time should you soak the filters in water as although they are a high-tech foam, they are still a foam and as such they will break down.

## tabletop

All **emendee**workstations have a glass surface.

- \* Clean with a detergent, disinfectant or methylated spirits.
- \* If you drop acrylic or gel onto the surface, wipe off with acetone immediately or allow to dry and this should 'click' off with pressure on the edge of the spill.

## workstationlegs

- \* Simply wipe over with a soft cloth.

## bestpractice

Getting the most from your **emendee**workstation

**emendee**workstations are tested and proven to remove more than 99% of the dust and 60% of the fumes, however there are a few things you need to do to get the best you can from your unit.

- \* When you first come into the salon turn on your **emendee**workstation
- \* Open all bottles of products over the filter
- \* Move your bottles to the edge of the filter. Your dapping dishes are able to sit on the filter itself to maximize vapour removal from your work area.
- \* When applying acrylic or gel, place your brush mat directly onto the filter and wipe the brush onto it. Remove the mat after and if there is any residue simply wipe with acetone
- \* If you have spilled acrylic or nail polish onto the filter – wipe off immediately with acetone. If you leave it to dry you can damage the filter when you try to remove it.
- \* Consciously work in the centre of the filter
- \* When you readjust your files, do it on the filter not on the table
- \* Before laying down your file, tap the file onto the filter
- \* If you are using an electric file make sure you are sitting up and out of the draw area of the unit
- \* Wipe your hands onto the filter not your clothes.

\* These things take a little time to become habits but are easily achievable. \*

## specialnotes

- \* Frigid air conditioning & cold areas without heating may experience some slight crystallisation of product. If this occurs simply place a piece of paper towel (not plastic backed) over Technician half of the primary filter. This will then stop the draw over the product but still allows vapour removal from your work area.  
  
\* Please note that this is only during the application of product and at all other times you should use your **emendee**workstation as normal \*
- \* Airbrushing with water based products can be conducted as normal with the filter being washed as previously described.
- \* On placing your **emendee**workstation consider any air currents that could interfere with the workstation's air draw. Cross flow standing fans or air conditioners facing across the unit can disrupt the delicate draw of the machine.